

SB2920-D6 Firmware Update Guide

You will need:



This Guide



Firmware Update
USB Thumb Drive*




VIZIO SB2920-D6 Sound
Bar


Updating the Sound Bar firmware:

1. Turn **ON** the Sound Bar and unplug it from the power outlet.
2. Plug the USB thumb drive into the USB port on the back of the Sound Bar.
3. Reconnect the Sound Bar to the power outlet with the power cable.
4. LEDs **1** and **2** will light, indicating that the update on the USB thumb drive has been found.

Note: LED indicators are located on the front of the Sound Bar.



5. LEDs **1, 3, and 4** will light, indicating that the firmware update is in progress. **Do not unplug the power cable or remove the USB thumb drive from the Sound Bar.** The LEDs will turn off when the update is completed.




6. Unplug the USB thumb drive from the Sound Bar.
7. Unplug the Sound Bar from the power outlet and plug it back in again.
8. The firmware update procedure is complete.
9. The LED indicators on the front of the Sound Bar will begin cycling in pairs through inputs until an audio source is detected.




Button Location:


Buttons are located on the top of the Sound Bar



1. Turn off the Sound Bar by pressing the **Power** button on the back.
2. **Press and hold** the **Volume Up**, **Volume Down**, and **Input** buttons for 5 seconds.
3. LEDs **2** and **3** will blink together six times.



4. LEDs **6** and **7** will blink together three times.



5. This signifies that firmware **version 2.4** (for SB2920-D6) has been successfully updated.

Do You Have Questions? Find Answers At
SUPPORT.VIZIO.COM

You can also contact our award-winning support team at:

Phone: (877) 878-4946 (TOLL-FREE)

Email: techsupport@VIZIO.com

Hours Of Operation:

Monday - Friday: 7 AM TO 11 PM (CST)

Saturday - Sunday: 9 AM TO 6 PM (CST)



Live Chat
Support Available